



Step 1: Install the Metal Horns

Begin by installing the metal horn tubes in the correct order. Start with the shortest bent tube A, then alternate between A and B tubes following the sequence $A \rightarrow B \rightarrow A \rightarrow B \rightarrow A \rightarrow B \rightarrow A$, until the final longest straight tube B is installed. Ensure each horn is firmly inserted and aligned.

Step 2: Connect the Wires

Each tube contains two wires: C (blue) and D (green). Gather all C wires together and connect them in parallel (C to C). Then gather all D wires together and connect them in parallel (D to D). After combining, you will have two final output wires. Connect these wires to the plug wires inside the base. Ensure all wire connections are secure and insulated.

Step 3: Attach the Bottom Pads

Apply the adhesive pads to the bottom of the base. This completes the assembly of the unit.