

INSTALLATION INSTRUCTIONS PROCEDURE

**STEP ONE**

Hooks equipped with non-marking nails are limited to installation on G-block and timber walls.

**STEP TWO**

Use a hammer to fully drive the non-marking nail into the wall (be careful not to hit the plastic parts of the nail)

**STEP THREE**

Align the card slot on the back of the hook with the non-marking nail and hang it on. The designed weight capacity is 5 kg. The actual weight capacity depends on the wall material.