

Installation Procedure


Before installing 5, connect power wire well, then put inside metal panel. 5

1 Installation of BLF-04

*Install sequence follows the numbers

For all screw holes, use M6 screw to fix, use rubber plug to insert the holes

The booth can be used while inserting power supply after installing



2 Installation of BLF-05

*Install sequence follows the numbers

For all screw holes, use M6 screw to fix, use rubber plug to insert the holes

